

MEASURING INSTRUCTIONS FOR:

## Panel Track


### Inside Mount:

*Standard Inside Mount:*


| Size (width)   | Minimum Depth Req'd |
|----------------|---------------------|
| 20" - 54"      | 1 1/8"              |
| 54 1/4" - 78"  | 1 1/8"              |
| 78 1/4" - 102" | 1 1/8"              |

*Or If Flush Mounting:*

| Size (width)   | Flush Mount Depth |
|----------------|-------------------|
| 20" - 54"      | 1 3/8"            |
| 54 1/4" - 78"  | 2 1/2"            |
| 78 1/4" - 102" | 3 1/4"            |




Measure Width




Measure Height

With a steel measuring tape, measure the width of the window/door frame opening at the top, middle, and bottom. Record the narrowest measurement. Then measure the height at the left, center, and right of the opening. Record the shortest measurement. Please make note of any projecting obstacles such as handles that would get in the way of the blind during operation. Also note the 15 1/2" stack width of vertical shades. If the stack width is going to interfere with the opening and closing of a door or patio door, then you may want to consider an outside mount. ***Please do not take any deductions from your actual measurements for an inside mount. A 1/2" deduction will be taken at our factory.***




← WIDTH →




15 1/2"  
STACKING  
WIDTH

### Outside Mount:

With a steel measuring tape, measure the width of the area you would like to cover at the top of the window or door frame (at least 3" beyond the window or door opening on each side). Record the measurement. Then measure the height of the area you would like to cover at the left, center and right (include at least 2 1/2" above the top of the window or door opening to allow for the height of mounting bracket). Record the largest measurement. Please note that if you are hanging the panels to the floor, you will need to subtract 1/2" from your height for floor clearance. If preferred, order the shade 15 1/2" wider in order to have the stack width be on the wall outside of the frame, rather than over the window/door opening. ***No deductions are taken from your actual measurements for an outside mount. The product will be made to the size specified.***



Measure Width



Measure Height